



XPLORER HOVERBOARD NEEDS TO BE CALIBRATED BEFORE THE FIRST USE!

1. Take the hoverboard out of the box and place it on even surface.
2. Press the ON/OFF button and hold it for 5 seconds until all lights on the hoberboard start blinking.
3. Align both platforms and make sure they are perfectly by using the level.
4. Leave the hoverboard in that position until it turns off (10-20 minutes, depending on the model). **Do not touch the hoverboard while calibration process is in progress!**
5. After the hoverboard turns off, the calibration process is complete and it is ready to use.